graflex

SERVICE BULLETIN

NO: 7
DATE: DECEMBER, 1968
REF: GENERAL

MANUFACTURING CODES

Each Graflex product is stamped with a three digit code showing date of manufacture. The first letter is the month, the second numeral is the year, and the third letter is the revision. The revision letter is changed when a new model is introduced or when a major modification is made to the equipment.

First-Letter		Second-Number		Third-Letter	
Letter	Month	Number	Year	Letter	Revision
A	Jan.	0	1960	A	1st
B	Feb.	1	1961	B	2nd
C	Mar.	2	1962	C	3rd
D	Apr.	3	1963	D	4th
E	May	4	1964	E	5th
F	June	5	1965	F	6th
G	July	6	1966	G	7th
H	Aug.	7	1967	H	8th
J	Sept.	8	1968	J	9th
K	Oct.	9	1969	K	10th
L	Nov.	0	1970	L	11th
M	Dec.	1	1971	M	12th

EXAMPLE: A product with the letters A6C would be one manufactured in January, 1966 to the 3rd modification.

LOCATION OF CODE

AUDIOVISUAL PRODUCTS

Graflex 16 Projector -- On main casting just above projection lamp or on serial number nameplate.

Messenger -- Under vinyl mat on turntable.

School Master Projector -- Bottom plate.

Overhead Projector -- Left vertical face of cord storage pan.

SM 1000 -- Inside projection lamp access door.

Compact Projector -- Upper part of film track; remove lens.

(OVER)

SM 400 Projector -- Bottom plate.

E-Z Viewer -- Inside of end cap.

PHOTOGRAPHIC PRODUCTS

Century Graphic Camera -- Bottom of bed yoke.

xl Camera Body -- Inside bottom of body.

Pacemaker Graphic Cameras -- Bottom of bed yoke.

Super Graphic Cameras -- Bottom of bed yoke.

Lens and Shutter Assemblies -- Back of lensboard.

xl Lens & Barrel Assemblies -- Next to cam in barrel.

Stroboflash Power Pack II & IV -- Tray.

Stroboflash Power Pack I -- Cap of Capacitor Assembly.

Stroboflash Lamphead -- Chassis frame and back of reflector.

120-220 Roll Film Holders -- Center leaf spring of carriage.

RH/50 Roll Film Holder -- Bottom Center of carriage.

Grafmatic Film Holder -- Inside back cover.

xl Polaroid Film Holder -- Left front side of adapter plate.

Strobomatic 500 Lamphead -- Back of reflector.

Strobomatic 500 Power Top -- Chassis frame.

Strobomatic 500 RG Base -- Bottom of battery compartment.

Strobomatic 500 AC Base -- Chassis frame.